



GENERAL INSTALLATION INSTRUCTIONS Bolt On Bury Extension

For Cast Leg Benches: Augustine, Lamplighter, Robinson, Rosedale, Schenley

PLEASE READ THESE STEPS BEFORE PROCEEDING

Included with your Bolt on Bury Extension is the following hardware:

- One (1) 3/8" Stainless Steel Flat Washer
- One (1) 3/8" Stainless Steel Nylon Lock Nut

Please abide by the following installation instructions:

1. Insert the threaded part of the extension up through the hole in the leg.
2. Place the washer over the thread and then screw on the lock nut. The washer should be between the nut and the leg.

