

## LITTER RECEPTACLE LANYARD REPLACEMENT

You will need the following tools to replace the lanyard that connects the litter receptacle with its lid:

1. Goggles
2. Drill
3. 3/16" drill bit. This drill bit needs to be strong enough to drill into the stainless steel rivet
4. A hand-held pop-rivet gun. You can purchase a pop-rivet gun at your local hardware store for minimal cost. (Approximately \$15.00-\$25.00)

One end of the lanyard needs to be attached to the litter receptacle and the other end of the lanyard attaches to the lid in the following manner:



- Always wear goggles and appropriate safety gear during installation.
- You will first need to drill out the old rivet from the litter receptacle. When you drill into the center of the existing rivet, it will remove the old rivet. **TAKE CAUTION** when you are drilling out the old rivet that you do not drill completely through the steel slat.
- To attach the new lanyard to the litter receptacle, place a rivet through the hole in the tab of the lanyard.
- Using a pop-rivet gun, secure the rivet into place.
- Follow the same instructions to attach the lanyard to the lid.

**\*\*\*Please take caution and follow these instructions carefully. Keystone Ridge Designs is not liable for structural damage or damage inflicted to the powder coat finish of the product during lanyard installation.**